

INFLPR




# MULTIFUNCTIONAL THIN FILMS OBTAINED BY MAPLE AND PLD TECHNIQUES LUIZA ADELINA CIUCU


National Institute for Laser Plasma & Radiation Physics  
(INFLPR), Bucharest, Romania




Motivation: replacing piezoelectric and ferroelectric lead-based materials



Motivation of BCTZ lead-free material study:  
replacing piezoelectric and  
ferroelectric lead-based materials



# Ferroelectric materials



## Properties

✓ Spontaneous polarization in the absence applied electrical field.



✓ Extremely high dielectric constant

✓ Non-linear dielectric response to an applied electrical field.

✓ High strain response to applied electrical field  $\Rightarrow$

**piezoelectricity**


✓ Strong variation in polarization with temperature  $\Rightarrow$  **pyroelectricity**




# Solid solution $(1-x)\text{Ba}(\text{Ti}_{0.8}\text{Zr}_{0.2})\text{O}_3 - x(\text{Ba}_{0.7}\text{Ca}_{0.3})\text{TiO}_3$ BCTZ- complex phase diagram



BCTZ ceramic systems are known to have high dielectric constant and high dielectric tunability. Impressive piezoelectric activity for composition  $0.5\text{Ba}(\text{Zr}_{0.2}\text{Ti}_{0.8})\text{O}_3 - 0.5(\text{Ba}_{0.7}\text{Ca}_{0.3})\text{TiO}_3$  – higher than that for PZT. Besides the MPB region, a C-T-R triple point or tricritical point has been found.




W. Liu and X. Ren, Phys. Rev. Lett. 103, 257602 (2009))



D.S. Keeble et al, Appl. Phys. Lett. 102, 092903 (2013)




# BCTZ complex phase diagram




Region of interest

W. Liu and X. Ren, Phys. Rev. Lett. 103, 257602 (2009))

# Laser methods




PLD technique



MAPLE technique



# Deposition methods of piezoelectric active layers



- Pulsed Laser Deposition, PLD, epitaxial thin films can be obtained for maximum piezoelectric activity. High temperatures are required during deposition. Piezoelectric active layers have been obtained on different supports ( $\text{MgO}$ ,  $\text{Al}_2\text{O}_3$ ,  $\text{SrTiO}_3$  )
- Matrix assisted Pulsed Laser Evaporations, MAPLE, room temperature deposition conditions, high areas can be obtained. Flexible supports have been used for piezoelectric active layers: kapton, Pt/Kapton









# Piezoelectric epitaxial thin films deposition by Pulsed Laser Deposition




## Morphology of the surface- Atomic Force Microscopy

Ceramic target:  
 $\text{Ba}_{0.865}\text{Ca}_{0.135}\text{Ti}_{0.89}\text{Zr}_{0.11}\text{O}_3$  (1500 °C – 4h)  
Substrates: Nb:STO  
Number of pulses:  
3000-36.0000




Demo sample of epitaxial layer for electrical testing

Piezoelectric studies: heterostructure to be obtained for integration of the piezoelectric active layer into a testing device



# Piezoelectric studies




-piezoresponse force microscopy technique has been employed for measuring the piezoelectric  $d_{33}$  coefficients of the thin films.




- Slightly lower values for the  $d_{33}$  coefficients for MAPLE thin films, but the major advantage is that the films can be obtained at room temperature from a frozen target.



# Biocompatibility studies performed on piezoelectric active layers.




HEK cells culture on  
piezoelectric layer deposited  
on Kapton



# CONCLUSIONS:

- Replacing piezoelectric and ferroelectric lead-based materials
- Spontaneous polarization in the absence applied electrical field.
- High strain response to applied electrical field.



# Thank you

[ciucu.luiza@yahoo.com](mailto:ciucu.luiza@yahoo.com)

